



We will begin momentarily at 2pm ET



Slides available now! Recordings will be available to ACS members after one week.

www.acs.org/acswebinars

Contact ACS Webinars ® at acswebinars@acs.org

1

Have Questions?



“Why am I muted?”
Don't worry. Everyone is muted except the presenter and host. Thank you and enjoy the show.

Type them into questions box!

Contact ACS Webinars ® at acswebinars@acs.org

2



Have you discovered the missing element?



www.acs.org/2joinACS

Find the many benefits of ACS membership!

3



Benefits of ACS Membership



Chemical & Engineering News (C&EN)
The preeminent weekly news source.



NEW! Free Access to ACS Presentations on Demand®
ACS Member only access to over 1,000 presentation recordings from recent ACS meetings and select events.



NEW! ACS Career Navigator
Your source for leadership development, professional education, career services, and much more.

www.acs.org/2joinACS

4

Let's get Social...post, tweet, and link to ACS Webinars during today's broadcast!



facebook.com/acswebinars



@acswebinars



Search for "acswebinars" and connect!



5

How has ACS Webinars® benefited you?



“Advanced Pyrotechnics: Flash, Sound, and Smoke was the best ACS Webinar I have seen to date. Excellent. Fast, relevant and well organized. Also had real, approachable chemistry, but not too detailed.”

Fan of the Week

Kirk Boyer
Component/Supplier Quality Engineer
Tektronix Component Solutions



Be a featured fan on an upcoming webinar! Write to us @ acswebinars@acs.org

6



facebook.com/acswebinars

@acswebinars

youtube.com/acswebinars

Stay connected...

Email us!

acswebinars@acs.org

ACS Webinars
CLICK • WATCH • LEARN • DISCUSS
www.acs.org/acswebinars

in Search for "acswebinars" and connect!

7



All recordings of ACS Webinars® will be available to current ACS members one week after the Live broadcast date.

Live weekly ACS Webinars® will continue to be available to the general public.

Contact ACS Webinars ® at acswebinars@acs.org

8

Upcoming ACS Webinars[®]

www.acs.org/acswebinars



Thursday, June 25, 2015

“Accelerating CNS Positron Emission Tomography (PET) Ligand Discovery”

Lei Zhang, Senior Principal Scientist, Pfizer Inc.

David Donnelly, Senior Research Investigator, Bristol-Myers Squibb



Thursday, July 7, 2015

“The Entrepreneurial Chemist: Bridging the Bench and the Boardroom”

Tashni-Ann Dubroy, Chemist and Entrepreneur, Tea and Honey Blends

Steven Isaacman, CEO and Founder, PHD Biosciences

Contact ACS Webinars[®] at acswebinars@acs.org

9

Past ACS Webinars[®]

The ACS Webinars Archive Explodes with Insight!



“Chemistry of Fireworks”

www.acs.org/content/acs/en/acs-webinars/popular-chemistry/chemistry-of-fireworks.html



“Advanced Pyrotechnics: Flash, Sound, and Smoke”

www.acs.org/content/acs/en/acs-webinars/popular-chemistry/advanced-fireworks.html

*Access to these recordings is an exclusive benefit for ACS Members.

Contact ACS Webinars[®] at acswebinars@acs.org

10



“Advanced Pyrotechnics 2: Ignition, Sensitivity, and Analysis of Energetic Materials”



Chris Mocella
Chemist and Co-Author of
“The Chemistry of Pyrotechnics”




Darren Griffin
Professor of Genetics,
University of Kent, UK

Slides available now! Recordings will be available to ACS members after one week
www.acs.org/acswebinars

Contact ACS Webinars ® at acswebinars@acs.org

11

Advanced Pyrotechnics 2: Ignition, Sensitivity, and Analysis of Energetic Materials



Analytical Chemists in the Wild West



Chris Mocella
ACS Webinar, June 2015

12

Review: Basics of Pyrotechnics

- Oxygen source (oxidizer) + electron source (fuel)
 - Products + Energy
- Energy Output =
 - Light (color)
 - Sound
 - Pressure
 - Motion
 - “The effect”



13

Ingredients for Pyrotechnic Mixes

- **Oxidizing Agents** (oxygen rich, occasionally fluorine)
- **Fuels** (organic, metallic, other)
- **Color ingredient**
- **Intensifier**
- **Binder** (small %, can also act as a fuel)

- Charcoal + KNO_3 + Sulfur = Black Powder
- Light a match → CO_2 , H_2O , K_2O , N_2 , SO_2 , “soot”, and

ENERGY!



14

Principles of Ignition



- **Ignition:** The ability to ignite/initiate the material using an *external stimulus* (with respect for stability of the material in the absence of the stimulus)
- For ignition to occur, a material must be heated to its *ignition temperature*, where the reaction will initiate and propagate
- The stimulus can be heat or flame, spark, as well as friction or impact, or some manner of *transferring energy* from the stimulus to the material, heating the chemicals
- What happens when sufficient stimulus is applied?



15


Ignition: Complexity and Propagation

- Upon sufficient stimulus, the materials will undergo a complex sequence of events, such as crystalline changes, melting, boiling, decomposition, interaction of liquid/vapor phases or fleeting decomposition products.
- These complex products and interactions take place on the materials and also in any visible flame.
- If the necessary activation energy has been applied, the reactions occur, more heat is evolved to give stimulus to unreacted material, propagating the reaction.



Ignition: Physical States

- **Requirement for ignition:** either the oxidizer or fuel to be in a liquid or vapor state to allow interaction
- Many oxidizers are **ionic solids** (KNO_3), and the “looseness” of the lattice is important in determining reactivity:
- Increased temperature, the vibrational motion of the lattice increases
- Liquid fuel components can more easily diffuse into the lattice, even if the oxidizer is still solid, and begin to interact below the melting or decomposition temperature



17

Audience Survey Question

ANSWER THE QUESTION ON BLUE SCREEN IN ONE MOMENT



Tammann Temperature is significant because?

- It is approximately two times the melting point in kelvin
- It is temperature at which the mobility and reactivity of the molecules in a liquid state become appreciable
- It has 70% of the vibrational freedom present at the melting point and can cause ignition in a reaction
- It is ideal temperature for ignition of any material

18

Tammann Temperature

- Prof G. Tammann proposed that this diffusion is significant at “halfway” to the melting point (the “Tammann temperature”) and has 70% of the vibrational freedom present at the melting point → often sufficient for reaction leading to ignition
- KNO_3 melts at 334 °C (607 K), but the Tammann temperature is 30.5 °C (303.5 K), just a hot day in August!

Oxidizer	Formula	Melting point, °C	Melting point, K	Tammann temperature, °C
Sodium nitrate	NaNO_3	307	580	17
Potassium nitrate	KNO_3	334	607	31
Potassium chlorate	KClO_3	356	629	42
Strontium nitrate	$\text{Sr}(\text{NO}_3)_2$	570	843	149
Barium nitrate	$\text{Ba}(\text{NO}_3)_2$	592	865	160
Potassium perchlorate	KClO_4	610	883	168
Lead chromate	PbCrO_4	844	1117	286
Iron oxide	Fe_2O_3	1565	1838	646
Magnesium metal	Mg	651	924	189



19


Sensitivity Analysis

- An energetic material must be sensitive to ignition if it is to be of any use
- But the safe handling and storage of the material must be of highest importance
- Understanding a material’s sensitivity is extremely important for storage and use, and therefore full sensitivity testing should be run on any new composition as a standard matter of course
- Thermal sensitivity
- Electrical/spark sensitivity (including static electricity)
- Impact sensitivity
- Friction sensitivity



20

Ignition Sensitivity Curve



A specified level of energy is applied – does ignition occur?
 → Ignition is a statistical event, therefore sensitivity is statistical



21

Audience Survey Question

ANSWER THE QUESTION ON BLUE SCREEN IN ONE MOMENT




Which of the following are viable Pyrotechnic Sensitivity Tests?

- Impact, sample, static, reference, and shock
- Zap, pow, boom, kapow, and bam
- Friction, thermal, booster, acceptor, and shock
- Impact, friction, electrostatic, thermal, and shock
- Audio, visual, scratch & sniff, tactile, and tongue



| 22

Types of Sensitivity Tests



Thermal Sensitivity

- At what temperature does the system ignite?
- Probably the best understood of all phenomenon
- Measured through DTA, DSC, time-to-ignition studies



Nitrocellulose – DSC and Time-To-Ignition Study



Spark Sensitivity

- Usually measured with a needle electrode (cathode) that approaches a sample sitting on a grounded surface (anode)
- The energy of the spark is controlled by varying capacitance and voltage and is measured in Joules $J=1/2 CV^2$
- Humans generate ~15-20 mJ (0.020 J) of energy, enough to ignite some compositions and many organic solvents (acetone, ethyl ether, methanol, etc)
- Conductive materials (metals) tend to increase the spark sensitivity of compositions
- Adding non-conductive materials (diatomaceous clay) can reduce the spark sensitivity (but also adversely affect the performance)



25

Spark Sensitivities

<u>Composition</u>	<u>Ignition Energy (J)</u>
RDX	> 4.5
Mg/NaNO ₃ /binder 55/40/5	> 4.5
Si/KNO ₃ 50/50	> 0.45 < 4.5
Al/KClO ₄ 22.5/77.5	> 0.04 < 0.45
Mg/BaO ₂ /Binder 12/86/2	> 0.001 < 0.045
B/MoO ₃ 25/75	0.00025


Source: J.M. Jenkins (UK); Lecture Notes (1980)



26

Static Electricity



- Every effort should be made to eliminate static electricity from the manufacturing and storage processes!



27

Friction Sensitivity

- A very important test, as many chances for friction to occur appear in production: mixing, pouring, pressing – generation of hot spots or interaction of materials at a chemical level
- Grittiness of the material can increase sensitivity (sometimes desired, sometimes not)
- Rotary friction – yields numerical value
- Sliding surface – yields a fire/no-fire result at a specific force



28

Rotary Friction Sensitivities

<u>Composition</u>	<u>Ignition Energy (ft-lb²/s)</u>
<i>IM 28 Incendiary</i>	19
Barium Nitrate 40	
Potassium Perchlorate 10	
Mg/Al Alloy 50	
<i>SW522 Smoke</i>	52
Potassium Perchlorate 20	
Potassium Nitrate 20	
Aluminum 20	
Zinc Dust 40	
<i>M22 Flash Mixture</i>	74,357
Magnesium (200/325) 75	
Teflon 10	
Viton 15	

Source: Aikman, et al; PEP 12, p.17 (1987).



29

Impact Sensitivity

- The DOT and DoD use the Bureau of Explosives (BoE) impact machine to determine impact sensitivity
- A specified weight is dropped from a specified height a specified number of times
- Cannot re-use a non-ignited sample (pressed)
- Usually reported in 10% or 50% ignition values, or minimum observed
- Generation of “hot spots” in the material



30

Impact vs. Friction Sensitivity

<u>% Comp. Zr/KClO₄</u>	<u>Impact Sens. Height of 50% Explosion (cm)</u>	<u>Friction Sens. Pistil Load upto which Insensitive (Kgf)</u>
10/90	115	36.0
20/80	106.5	36.0
30/70	106.25	36.0
40/60	90.0	14.4
50/50	92.5	10.8
60/40	99.1	5.4
70/30	92.5	4.8
80/20	103.0	3.6
90/10	94.0	2.0



31

Factors Affecting Sensitivity

- Homogeneity
- Particle morphology and size
- Grain size of blended material
- Residual moisture or organic solvent
- Formula and percent composition
- Presence of grit, foreign material, acids, bases
- Chemical incompatibility (acids, moisture, etc)
- Changes to ANY ONE of these will affect sensitivity
- Be warned of static electricity!



32

Instrumental Analysis

- Modern instruments and methods have provided pyrotechnicians with substantial new abilities and a wealth of information.

Ability to Study and Analyze:

- Chemical makeup and purity
- Ignition processes
- Sensitivity to ignition
- Micro-structure of solids and mixture layouts
- Thermal/barometric behavior and output
- Reaction products
- Quantification of visual and auditory effects
- Effects of external stimuli (environment, time) on compositions



33

STAND BACK



I'M GOING TO TRY
SCIENCE

Some Instrumentation and Techniques

- Differential Thermal Analyzer (DTA)
- Differential Scanning Calorimeter (DSC)
- Spark Sensitivity Device
- Impact/Shock Sensitivity Device
- Friction Sensitivity Device
- Microscopy
- Particle Size Analyzer
- Fourier-Transform Infrared Spectrometer (FTIR)
- Ultraviolet-Visible Spectrometer (UV-Vis)
- Thermogravimetric Analyzer
- X-Ray Crystallography
- X-Ray Diffraction
- Gas chromatography
- Atomic Emission Spectroscopy
- Optical Emission Spectroscopy
- Raman Spectroscopy
- Nuclear Magnetic Resonance (NMR)
- X-Ray Fluorescence Spectroscopy
- Moisture analysis
- Calorimeter
- Barometer
- Voltmeter
- Liquid Chromatography
- Mass Spectrometry
- Atomic Absorption Spectroscopy
- Flame Ionization Detector
- Footcandle Light Meter
- Volume Unit Meter
- Densitometer
- Ion-Mobility Spectrometry
- Neutron Diffraction Crystallography
- Pyrolysis Effluent Gas Detection (EGD)
- Melting point apparatus



35


Emission Spectroscopy Uses

- Quantifying color output of colored compositions
- But remember: the human eye is not an electronic spectrometer, it is much more complicated!
- What looks like a **fantastic green** on the computer may be “**rather meh...**” to the human eye, or vice-versa.
- Optical Emission Spectroscopy (OES) - determination of purity of compounds, including identification of impurities with quantification
 - Extra sodium causing too much yellow to **overpower**, too much **strontium** in the **barium** compound, etc.




36

Red Flare Emission Spectrum



37

Green Flare Emission Spectrum



38

Microscopy

- “Looking small”
- Using microscopes to enhance visualization material that may not be visible with the naked eye
- Optical - standard magnifying glass/microscope
- Electron – using a beam of electrons to illuminate the specimen
 - TEM – transmission electron microscope (older) – maps the resulting diffracted electrons to form the image
 - SEM – scanning electron microscope (modern) – analyzes resulting emissions to determine map of the target
- Scanning – using a physical probe to scan the surface
 - STM – scanning tunneling microscopy
 - ATM – atomic force microscopy




39

KNO_3 under a Microscope





40

SEM Of Thermite - Al/Fe₂O₃





41

Optical/SEM of Activated Charcoal



42

STM of TNT



43

Thermoanalysis

- Study of the thermal properties of compositions is exceedingly valuable to the pyrotechnician:
- Ignition temperature/time-to-ignition
- Burning temperature
- Calorimetry
- Differential Thermal Analysis (DTA)
- Differential Scanning Calorimetry (DSC)
- Thermal Gravimetry (TG)
- Evolved Gas Analysis (EGA)
- Pyrolysis – Analysis of effluent gas



44

Ignition Temperature



- Measured temperature of ignition of a composition
- Decomposition or activation of materials to allow interaction
 - Release of oxygen/oxidizer
 - Fuel in a state to be oxidized
- Rate of heat release must be sufficient to sustain further burning
- Measured by direct heat application (when did it burn?), DTA, or DSC



45


DTA

- Differential Thermal Analysis – measures the difference in temperature between an analyte and reference sample (that just gets hot at a steady rate)
- Endotherm – analyte not increasing in temperature with reference
- Exotherm – analyte hotter than reference



46

Thermogram of Potassium Nitrate




130 °C – rhombic to trigonal crystalline transition (requires energy/heat)
334 °C - melting



47

Thermogram of Sulfur




105 °C – rhombic to monoclinic crystalline change
119 °C – melting
180 °C – fragmentation of liquid S8 into smaller units
450 °C – vaporization



48

Thermogram of Black Powder



- 105/119 °C – Solid phase transition and melting of sulfur (overlap)
- 130 °C – rhombic to trigonal crystalline transition
- 334 °C – potassium nitrate melting, followed by exotherm (ignition)
- Release of oxygens from KN major player in ignition

49

Conclusion: Analyzing your Composition

- Microscopy
- Suite of sensitivity tests
- Thermal analysis / ignition temperatures
- Functional analysis (did it work?)
- Analysis of desired output:
- Color – spectroscopy
- Light/Obscuration – photometry/light meter
- Gas generation – TGA/gas analyzer
- Sound – sound level meter/loudness meter
- Chemical analysis/Forensics – Chromatography/mass spec, IR, UV-Vis, Raman, x-ray fluorescence, x-ray diffraction, &c



50

Safety!



- All pyrotechnic compositions are sensitive to some form of stimulus: heat/flame, spark, shot, friction, shock
- Every effort needs to be made to handle materials safely
- Do not experiment with chemicals that you do not understand!



51

Other Resources

- A.A. Shidlovskiy, Principles of Pyrotechnics
- T. Shimizu, Fireworks, The Art, Science, and Technique
- J.A. Conkling, C.J. Mocella, Chemistry of Pyrotechnics
- Journal of Pyrotechnics, Pyrotechnic Chemistry
- American Pyrotechnics Association
- Pyrotechnics Guild International
- Local hobbyist clubs



52

Audience Survey Question

ANSWER THE QUESTION ON BLUE SCREEN IN ONE MOMENT




What is your favorite memory of a fireworks show?

- Independence Day (U.S.)
- Bonfire Night/Guy Fawkes Night (U.K)
- Setting off snappers and bottle rockets as a kid
- New Year / Chinese New Year
- [Can't tell you, we bent some laws doing it, but it was AWESOME!]

| 53

Thanks For Attending!





“Advanced Pyrotechnics 2: Ignition, Sensitivity, and Analysis of Energetic Materials”



Chris Mocella
Chemist and Co-Author of
“The Chemistry of Pyrotechnics”



Darren Griffin
Professor of Genetics,
University of Kent, UK

Slides available now! Recordings will be available to ACS members after one week
www.acs.org/acswebinars

Contact ACS Webinars® at acswebinars@acs.org

55

Past ACS Webinars®

The ACS Webinars Archive Explodes with Insight!



“Chemistry of Fireworks”

www.acs.org/content/acs/en/acs-webinars/popular-chemistry/chemistry-of-fireworks.html



“Advanced Pyrotechnics: Flash, Sound, and Smoke”

www.acs.org/content/acs/en/acs-webinars/popular-chemistry/advanced-fireworks.html

*Access to these recordings is an exclusive benefit for ACS Members.

Contact ACS Webinars® at acswebinars@acs.org

56

Upcoming ACS Webinars®

www.acs.org/acswebinars



Thursday, June 25, 2015

“Accelerating CNS Positron Emission Tomography (PET) Ligand Discovery”

Lei Zhang, Senior Principal Scientist, Pfizer Inc.

David Donnelly, Senior Research Investigator, Bristol-Myers Squibb



Thursday, July 7, 2015

“The Entrepreneurial Chemist: Bridging the Bench and the Boardroom”

Tashni-Ann Dubroy, Chemist and Entrepreneur, Tea and Honey Blends

Steven Isaacman, CEO and Founder, PHD Biosciences

Contact ACS Webinars® at acswebinars@acs.org

57



“Advanced Pyrotechnics 2: Ignition, Sensitivity, and Analysis of Energetic Materials”



Chris Mocella

Chemist and Co-Author of
“The Chemistry of Pyrotechnics”



Darren Griffin

Professor of Genetics,
University of Kent, UK

Slides available now! Recordings will be available to ACS members after one week

www.acs.org/acswebinars

Contact ACS Webinars® at acswebinars@acs.org

58

How has ACS Webinars® benefited you?




Be a featured fan on an upcoming webinar! Write to us @ acswebinars@acs.org ⁵⁹



 facebook.com/acswebinars
 [@acswebinars](https://twitter.com/acswebinars)
 youtube.com/acswebinars



 Search for “acswebinars” and connect!

60



Benefits of ACS Membership



Chemical & Engineering News (C&EN)

The preeminent weekly news source.



NEW! Free Access to ACS Presentations on Demand®

ACS Member only access to over 1,000 presentation recordings from recent ACS meetings and select events.



NEW! ACS Career Navigator

Your source for leadership development, professional education, career services, and much more.

www.acs.org/2joinACS

61



ACS Webinars® does not endorse any products or services. The views expressed in this presentation are those of the presenter and do not necessarily reflect the views or policies of the American Chemical Society.



Contact ACS Webinars ® at acswebinars@acs.org

62

Upcoming ACS Webinars[®]

www.acs.org/acswebinars



Thursday, June 25, 2015

“Accelerating CNS Positron Emission Tomography (PET) Ligand Discovery”

Lei Zhang, Senior Principal Scientist, Pfizer Inc.

David Donnelly, Senior Research Investigator, Bristol-Myers Squibb



Thursday, July 7, 2015

“The Entrepreneurial Chemist: Bridging the Bench and the Boardroom”

Tashni-Ann Dubroy, Chemist and Entrepreneur, Tea and Honey Blends

Steven Isaacman, CEO and Founder, PHD Biosciences

Contact ACS Webinars[®] at acswebinars@acs.org

63